

RS50 & RS51 4-Slot Battery Charger >

Quick Start Guide


EN

>>

EN

Overview

- Open Your Box:** ☒ 4-Slot Battery Charger
☒ Adapter plus Power Cord ☒ Quick Start Guide



Important Charging Information

Power Supply	Input: AC 100-240V, 47-63Hz Output: DC 12V $\pm$ 5%, 3.3A (Maximum) CipherLab approved
Battery Pack (optional)	3.8V, 4000mAh / 3.75V, 5300mAh rechargeable Li-ion, CipherLab proprietary
Charging Time	Approx. 5 hours (4000mAh) / 6 hours (5300mAh)
Charging Temperature	0°C - 45°C

LED Indicators

The status LED on the RS50/RS51 4-slot battery charger shows the charging status:


Charging LED Status

Green, solid	Charging complete
Red, solid	Charging the battery
Red, blinking	Charging error (for instance, the charging temperature is out of the valid range)

Charging

Step 1:



Connect the power cord with the adapter, and plug the power cord to an electrical outlet.



Step 2:

Plug adapter plug to the power jack of the 4-Slot Battery Charger.

Contact Pins



Step 3:

Insert the battery into the charging compartment with the battery contact pins connected to the contact pins inside the battery compartment.

RS50/RS51 四槽電池充電器 快速使用指南

繁中 簡中


RS50/RS51 四槽電池充電器 快速使用指南

繁中 簡中

概覽／概览

檢視包裝內容物／检视包装内容物：

- ☑ 四槽電池充電器／四槽电池充电器
- ☑ 電源轉換器，附電源線／电源转换器，附电源线
- ☑ 快速使用指南／快速使用指南



重要電源資訊／重要电源信息

電源轉換器 电源转换器	輸入／输入：AC 100-240V, 47-63Hz 輸出／输出：DC 12V± 5%, 3.3A (最大) CipherLab專用電源供應器／专用电源供应器
電池容量 (可選) 电池容量 (可选)	3.8V, 4000mAh / 3.75V, 5300mAh CipherLab 專用充電式鋰電池 CipherLab 专用充电式锂电池
充電時間／充电时间	4000mAh 約 5 小時 / 4000mAh 约 5 小时 5300mAh 約 6 小時 / 5300mAh 约 6 小时
充電溫度／充电温度	0°C - 45°C

LED 指示燈／LED 指示灯

四槽充電器上的充電指示燈顯示充電資訊。

四槽充电器上的充电指示灯显示充电信息。

LED指示燈狀態說明／LED指示灯状态说明

綠燈恆亮／绿灯恒亮	充電完成／充电完成
紅燈恆亮／红灯恒亮	電池充電中／电池充电中
紅燈閃爍／红灯闪烁	充電錯誤／充电错误 (如：超出可充電的溫度範圍 ／如：超出可充电的温度范围)

充電／充电

步驟1：

將電源線一端連接到電源轉換器，
另一端連接到插座。



步驟1：

將電源線一端連接到電源轉換器，另一端連接到插座。

步驟2：將電源轉換器接頭連接到四槽電池充電器的電源孔。

步骤2：将电源转换器接头连接到四槽电池充电器的电源孔。

金屬接點／金属接点



步驟3：將電池放入四槽充電器的插槽中。電池的金屬接點須對準充電器電池槽中的金屬接點。

步骤3：将电池放入四槽充电器的插槽中。电池的金属接点须对准充电器电池槽中的金属接点。