


# RK25 Snap-on Charging and Comm. Cable Quick Start Guide

&gt;

EN

The Snap-on Cable allows convenient charging and data transmission of the RK25 mobile computer. Please refer to the RK25 reference manual for more details on using the RK25 mobile computer.

## Overview



### Important Charging Information


|               |                                                                                   |
|---------------|-----------------------------------------------------------------------------------|
| Power Supply  | Input: AC 100 - 240V, 47 - 63Hz<br>Output: 4.75V - 5.4V, 2A<br>CIPHERLAB approved |
| Battery Pack  | 3.8V, 4000mAh rechargeable Li-Polymer battery,<br>CIPHERLAB proprietary           |
| Charging Time | Approx. 4 hours via adapter                                                       |

## Installation

**Warning:**  
*The micro USB cable must be removed from RK25 device before installing the snap-on cable.*

**Step 1:** Hold the snap-on cup toward the bottom of the RK25 mobile computer, and place one of the snap-on cup side to the side of the RK25 mobile computer.

**Step 2:** Push the Snap-on cup upwards to make its another side to be attached to the RK25 mobile computer.



&gt;&gt;

EN

### Step 3:

A "click" sound is made once the Snap-on cable is connected with the bottom of the RK25 mobile computer in place.

### Step 4:


Connect the USB plug to the approved adapter for external power connection, or plug it to the USB port of PC/laptop for data transmission/ charging.



## Remove

**Step 1:** Pull aside one side of the snap-on cup to make it part with the side of the RK25 mobile computer.

**Step 2:** Pull down the snap-on cable & pull up the RK25 mobile computer at the same time.



## LED Indicator on the RK25 Mobile Computer

While the device battery is being charged via the Snap-on cable, the LED on the mobile computer will indicate charging status:

| LED Indicator | Status       | Description                          |
|---------------|--------------|--------------------------------------|
| Charging      | Red, solid   | Charging the mobile computer         |
|               | Red, blink   | Charging error                       |
|               | Green, solid | Charging complete                    |
|               | No light     | The cable is not correctly connected |


# RK25 卡扣式傳輸充電線

## 快速開始指南

> 繁體 簡體

卡扣式充電傳輸線可用於進行RK25行動電腦的充電及資料傳輸，而關於RK25行動電腦的使用方式，請參考行動電腦的操作手冊。  
卡扣式充電傳輸線可用於進行RK25行動電腦的充電及資料傳輸，而關於RK25行動電腦的使用方式，請參考行動電腦的操作手冊。

## 概覽／概览



## 重要電源資訊／重要电源信息

|                |                                                                                                                                              |
|----------------|----------------------------------------------------------------------------------------------------------------------------------------------|
| 電源轉換器<br>电源转换器 | 輸入：AC 100 - 240V, 47 - 63Hz；輸出：4.75V - 5.4V, 2A<br>CipherLab 專用電源供應器<br>输入：AC 100 - 240V, 47 - 63Hz；输出：4.75V - 5.4V, 2A<br>CipherLab 专用电源供应器 |
| 電池容量／电池容量      | 3.8V, 4000mAh, CipherLab 專用充電式鋰聚合物電池<br>3.8V, 4000mAh, CipherLab 专用充电式锂聚合物电池                                                                 |
| 充電時間／充电时间      | 以電源轉換器充電約4小時／以电源转换器充电约4小时                                                                                                                    |

## 安裝／安装

**警告：**請務必先移除連接於RK25主機上的Micro USB線，再安裝卡扣式傳輸充電線。  
**警告：**请务必先移除连接于RK25主机上的Micro USB线，再安装卡扣式传输充电线。

**步驟1：**將傳輸充電槽對準RK25行動電腦底部，並將傳輸充電槽其一側邊與RK25行動電腦的側邊接合。

**步驟1：**将传输充电槽对准RK25行动电脑底部，并将传输充电槽其一侧边与RK25行动电脑的侧边接合。

**步驟2：**上推傳輸充電槽，使其另一側邊與RK25主機接合。


**步驟2：**上推传输充电槽，使其另一侧边与RK25主机接合。



# RK25 卡扣式传输充电线

## 快速开始指南

>> 繁體 簡體



**步驟3：**當傳輸充電槽確切連接卡上RK25行動電腦底部時，會發出『喀』聲。

**步驟3：**当传输充电槽确切连接卡上RK25行动电脑底部时，会发出『喀』声。


**步驟4：**將USB插頭接上電源轉換器，進行外部電源連接；或插入電腦的USB埠進行資料傳輸／充電。

**步驟4：**将USB插头接上电源转换器，进行外部电源连接；或插入电脑的USB埠进行文件传输／充电。

## 卸除／卸除

**步驟1：**將傳輸充電槽的任一側邊向外拉開，使其與RK25行動電腦側邊分開。  
**步驟1：**将传输充电槽的任一侧边向外拉开，使其与RK25行动电脑侧边分开。

**步驟2：**下拉傳輸充電槽，同時將RK25行動電腦上移取出。  
**步骤2：**下拉传输充电槽，同时将RK25行动电脑上移取出。



## LED指示燈號／LED指示灯号

RK25行動電腦主電池充電時，螢幕右上方的LED充電狀態指示燈將亮起，顯示充電狀態：  
RK25行动电脑主电池充电时，萤幕右上方的LED充电状态指示灯将亮起，显示充电状态：

| LED 指示燈<br>LED 指示灯 | 狀態／状态     | 說明／说明                                        |
|--------------------|-----------|----------------------------------------------|
| 充電／充电              | 紅燈恆亮／红灯恒亮 | 行動電腦充電中／行动电脑充电中                              |
|                    | 紅燈閃爍／红灯闪烁 | 充電錯誤（充電將會停止）<br>充电错误（充电将会停止）                 |
|                    | 綠燈恆亮／绿色恒亮 | 充電完成／充电完成                                    |
|                    | 沒有燈亮／没有灯亮 | 無法充電（充電線端未正確連接本機或插座）<br>无法充电（充电线端未正确连接本机或插座） |