


제품 구성

- ✓ RK25 모바일컴퓨터
- ✓ AC 어댑터 (선택)
- ✓ MicroUSB 케이블 (선택)
- ✓ 스냅-온 충전/통신 케이블 (선택)
- ✓ 핸드스트랩 (선택)
- ✓ 퀵스타트 가이드

각 부분 명칭




- 1. LED 상태표시등
- 2. 리시버
- 3. 터치스크린
- 4. 스캔 키
- 5. 마이크
- 6. 헤드셋 연결잭
- 7. 측면 트리거 키
- 8. Micro USB포트
- 9. 카메라
- 10. 플래시
- 11. 핸드스트랩 커버
- 12. 커버일체형 배터리
- 13. 배터리래치
- 14. 스피커
- 15. 볼륨 버튼
- 16. 핸드스트랩 연결고리
- 17. 충전/통신 핀
- 18. 전원버튼
- 19. 스캔 창

배터리 장착 및 분리

다음의 단계를 따라 배터리 장착 및 분리를 진행해주세요.


Step 1: 배터리래치의 잠금 장치를 눌러주세요

Step 2: 배터리래치를 오른쪽으로 밀어 잠금을 풀어주세요.
배터리가 약간 들어올려져 분리 가능한 상태가 됩니다.



Step 3: 커버일체형 배터리의 두 측면을 잡고
아랫부분부터 들어올리면서
기기에서 분리해주세요

Step 4: 충전된 배터리의 윗부분을
먼저 기기에 끼운 뒤에
아랫부분을 눌러 장착해주세요.



Step 5: 배터리래치를 왼쪽으로 밀어
배터리를 잠가주세요.



Note:
꼭 충전된 배터리를 장착해주시고,
전원을 켜기 전에 배터리래치가 '잠금' 상태에 있는지 확인해주세요.

SIM카드 & SD카드 장착

Step 1: 커버일체형 배터리를 분리해주세요.




Note: SIM소켓은 기기에 따라
MicroSIM소켓이 한 개 또는 두 개일 수 있습니다.

**MicroSIM 카드만
장착이 가능합니다.**

Step 2: 소켓덮개를 뒤로 밀고 덮개 윗부분을 들어 소켓을 열어주세요.


Step 3: 카드를 금속 부분이 아랫면을 향하게 한 후 소켓에 끼워주세요.

Step 4: 소켓덮개를 닫은 후 다시 앞으로 밀어 잠가주세요



Step 5:
배터리를 장착하고
배터리래치를 잠가주세요.

기기 충전 및 통신




USB케이블 사용 시

RK25 모바일컴퓨터 우측에 있는
USB포트에 MicroUSB케이블을
연결해주세요.

그리고 USB 케이블의 반대쪽을
PC 또는 노트북에 연결해 충전
또는 데이터통신을 진행하세요.

Warning:

기기에 USB케이블과 스냅-온 케이블을 함께 연결하지 마세요.



스냅-온 충전/통신 케이블 사용 시

스냅-온 케이블을 잡고 RK25 모바일컴퓨터의
아래 쪽을 바라보게 한 후, 위로 밀어 올려
RK25 모바일컴퓨터에 장착해주세요.

반대 편에 있는 USB플러그에 인증된 어댑터를
연결해 기기를 충전하거나, PC 또는 노트북에
연결해 충전 또는 데이터통신을 진행하세요.

전원 사양

전원 공급	Input: AC 100-240 V, 50/60 Hz Output: DC 5V, 2A, CipherLab approved KC
배터리 사양	3.8V, 4,000mAh 리튬 폴리머 충전 배터리
충전 시간	약 4시간 (어댑터 사용)

규정 정보란에서 제품의 인증 정보를 확인하세요

설정 → 휴대전화 정보 → 규정 정보

RK25 Mobile Computer

Quick Start Guide

>
EN


>>
EN

>>>
EN

Open Your Box

- ✓ RK25 Mobile Computer
- ✓ AC Adapter (Optional)
- ✓ Micro USB Cable (Optional)
- ✓ Snap-on Charging & Communication Cable (Optional)
- ✓ Hand Strap (Optional)
- ✓ Quick Start Guide

Overview




Install & Remove Battery

Please follow the steps to remove and install the main battery.


Step 1: Keep pressing down the lock button on battery latch.

Step 2: Slide the battery latch rightward to the "Unlock" position.
The battery cover slightly tilt up and is ready to be removed.



Step 3:
By holding the two sides of the battery cover, lift up the main battery (which is with the battery cover) from its lower end to remove it.


Step 4:
Insert a fully-charged main battery from its upper end, and then press down the lower edge of the battery.



Note: Please insert a charged battery, and make sure the battery latch is at the "Lock" position before powering on the device.

Install SIM Card & SD Card


Step 1: Remove the battery which is with the battery cover.




Step 2: Slide the hinged cover backward, and swing the top to open the socket.

Step 3: Place the card into the socket with its metal contacts downward.

Step 4: Close the hinged cover, and then push it toward to lock.



Charging & Communication



Warning:
Do NOT connect the RK25 mobile computer with USB cable & the snap-on cable at the same time.

Important Charging Information	
Power Supply	Input: AC 100-240 V, 50/60 Hz Output: DC 5V, 2A, CipherLab approved KC
Battery Pack	3.8V, 4000mAh rechargeable Li-polymer battery CipherLab proprietary
Charging Time	Approx. 4 hours via adapter