


Open Your Box

- ✓ RK25WO Mobile Computer (28-Key Model or 25-Key Model)
- ✓ AC Adapter (Optional)
- ✓ Micro USB Cable (Optional)
- ✓ Snap-on Charging & Communication Cable (Optional)
- ✓ Hand Strap (Optional)
- ✓ Quick Start Guide

Overview




- 1. Status LED
- 2. Receiver
- 3. Touchscreen
- 4. Scan Key
- 5. Microphone
- 6. Headset Jack
- 7. Side-Trigger
- 8. Micro USB Port
- 9. Camera
- 10. Camera Flash
- 11. Hand Strap Hole
- 12. Battery (with battery cover)
- 13. Battery Cover Latch
- 14. Speaker
- 15. Volume Buttons
- 16. NFC Detection Area
- 17. Hand Strap Hole
- 18. Charging & Communication Pins
- 19. Power Button
- 20. Scan Window

Communication with NFC

Step 1:
On the mobile computer, launch an NFC enabled application.

Step 2:
Hold the mobile computer without covering NFC detection area.

Step 3:
Simply move the mobile computer in proximity with the NFC tag or device until the application indicates data transfer is complete.




Install & Remove Battery

Please follow the steps to remove and install the main battery.

Step 1: Keep pressing down the lock button on battery latch.

Step 2: Slide the battery latch rightward to the "Unlock" position.
The battery cover slightly tilt up and is ready to be removed.



Step 3:
By holding the two sides of the battery cover, lift up the main battery (which is with the battery cover) from its lower end to remove it.


Step 4:
Insert a fully-charged main battery from its upper end, and then press down the lower edge of the battery.

Step 5: Slide the battery latch leftward to "Lock" position.


Note: Please insert a charged battery, and make sure the battery latch is at the "Lock" position before powering on the device.

Install SD card

Step 1:
Remove the battery which is with the battery cover.




Step 2: Slide the hinged cover backward, and swing the top to open the socket.
Step 3: Place the card into the socket with its metal contacts downward.
Step 4: Close the hinged cover, and then push it toward to lock.




Step 5: Place the battery cover back and push the battery latch to the "Lock" position.

Charging & Communication



By USB cable:
Insert a micro USB cable into its port on the right side of the RK25WO mobile computer. Connect another end to PC/ Laptop for charging/ data transmission.



By Snap-on Charging & Communication cable:
Hold the snap-on cup toward the bottom of the RK25WO mobile computer, and push the snap-on cup upwards to make it attach to the RK25WO mobile computer. Connect the USB plug to the approved adapter for external power connection, or plug it to the USB port of PC/laptop for charging/ data transmission.

Important Charging Information

Power Supply	Input: AC 100-240 V, 50/60 Hz Output: DC 5V, 2A, CipherLab approved BSMI, CCC, FCC, CE, RCM, PSE, PSB, BIS, KC
Battery Pack	3.8V, 4000mAh rechargeable Li-polymer battery CipherLab proprietary
Charging Time	Approx. 4 hours via adapter

RK25WO 行動電腦
快速使用指南

繁體中文 簡體中文

RK25WO 行动电脑
快速使用指南


繁體中文 簡體中文

繁體中文 簡體中文

檢視包裝內容物／检视包装内容物

- ✓ RK25WO行動電腦／RK25WO行动电脑 (28鍵機型 或 25鍵機型 / 28键机型 或 25键机型)
- ✓ 電源轉換器 (選配)／电源适配器 (选配)
- ✓ Micro USB傳輸線 (選配)／Micro USB传输线 (选配)
- ✓ 卡扣式傳輸充電線 (選配)／卡扣式传输充电线 (选配)
- ✓ 手腕帶 (選配)／手腕带 (选配) ✓ 快速使用指南／快速使用指南

概覽／概览



1. LED指示燈／LED指示灯

2. 聽筒／听筒

3. 觸控螢幕／触控屏幕

4. 掃描鍵／扫描键

5. 話筒／话筒

6. 耳機孔／耳机孔

7. 側面按鍵／侧面按键

8. Micro USB連接埠／Micro USB连接埠

9. 相機／相机

10. 相機閃光燈／相机闪光灯
11. 手腕帶固定孔／手腕带固定孔

12. 電池(蓋)／电池(盖)

13. 電池蓋開關／电池盖开关

14. 擴音器／扩音器

15. 音量鍵／音量键

16. NFC 偵測區域／NFC侦测区域

17. 手腕帶固定孔／手腕带固定孔

18. 充電接點／充电接点

19. 電源鍵／电源键

20. 掃描窗／扫描窗

使用NFC傳輸／使用NFC传输

步驟1／步骤1：
啟動行動電腦上的NFC應用程式。
启动行动电脑上的NFC应用。

步驟2／步骤2：
握住行動電腦，勿遮蔽NFC偵測區域。
握住行动电脑，勿遮蔽NFC侦测区域。

步驟3／步骤3：
將行動電腦靠近NFC標籤或裝置，直至應用
程式顯示傳輸完畢。
将行动电脑靠近NFC标签或装置，直至应用显示传输完毕。




電池安裝與拆卸／电池安装与拆卸

請依步驟指示拆卸並安裝主電池／请依步骤指示拆卸并安装主电池：

步驟1：持續按住電池蓋門扣。／步骤1：持续按住电池盖门扣。

步驟2：往右推至「解鎖」位置。電池蓋些微向上翹開，可進行主電池移除。
步骤2：往右推至「解锁」位置。电池盖些微向上翘开，可进行主电池移除。



步驟3：
請握住電池蓋左右兩側，由主電池
(與電池蓋為一體) 下端抬起以移除。

步驟3：
请握住电池盖左右两侧，由主电池
(与电池盖为一体) 下端抬起以移除。

步驟4：
請使用充飽電之主電池，先由電池
上端插入電池槽，再下壓底端。

步驟4：
请使用充饱电之主电池，先由电池
上端插入电池槽，再下压底端。


步驟5：將電池蓋門扣左推
至「上鎖」位置。

步驟5：将电池盖门扣左推
至「上锁」位置。


安裝SD卡／安装SD卡

步驟1：移除電池蓋
／步骤1：移除电池盖

Micro SD 卡槽
支援SD/SDHC/SDXC




步驟2：請將鉸接蓋後推，再翻開／步骤2：请将铰接盖后推，再翻开
步驟3：請直接將卡片放入或取出／步骤3：请直接将卡片放入或取出
步驟4：蓋上鉸接蓋，再往前推上鎖／步骤4：盖上铰接盖，再往前推上锁



步驟5：重新蓋上電池蓋，將電池蓋門扣推回鎖上的位置。
步骤5：重新盖上电池盖，将电池盖门扣推回锁上的位置。


充電與傳輸／充电与传输



透過USB線／透过USB线：

將micro USB線插入RK25WO
行動電腦右側的micro USB
埠。而micro USB線的另
一端則連接至電腦進行充
電／傳輸。

將micro USB線插入RK25WO
行动电脑右侧的micro USB
埠。而micro USB线的另
一端则连接至电脑进行充
电／传输。



透過卡扣式傳輸充電線／透过卡扣式传输充电线：

將傳輸充電槽對準RK25WO行動電腦底部，上推
傳輸充電槽，使其與RK25WO行動電腦接合。將
USB插頭接上電源轉換器，進行外部電源連接；
或插入電腦的USB埠進行資料傳輸／充電。

将传输充电槽对准RK25WO行动电脑底部，上推
传输充电槽，使其与RK25WO行动电脑接合。将
USB插头接上电源转换器，进行外部电源连接；
或插入电脑的USB埠进行文件传输／充电。

重要電源資訊／重要电源信息

電源轉換器 电源适配器	輸入／输入：AC 100-240 V, 50/60 Hz；輸出／输出：DC 5V, 2A CipherLab專用電源供應器／CipherLab专用电源供应器 BSMI, CCC, FCC, CE, RCM, PSE, PSB, BIS, KC
電池容量 电池容量	3.8V, 4000mAh, CipherLab專用充電式鋰聚合物電池 3.8V, 4000mAh, CipherLab专用充电式锂聚合物电池
充電時間 充电时间	以電源轉換器充電約4小時／以电源适配器充电约4小时