

RK25 5スロットクレイドル クイックスタートガイド

>

日本語

>>


日本語

RK25 5スロットクレイドルは5台のRK25端末を同時充電することができます。

外観

内容物の確認：

- ☑ RK25 5スロットクレイドル
- ☑ 付属電源アダプター、電源ケーブル
- ☑ クイックスタートガイド



電源に関する重要情報

電源アダプター	入力：AC 100-240V, 47-63Hz；出力：DC 12V±5%, 8-10A CipherLab専用電源アダプター
バッテリー容量	3.8V, 4000mAh, CipherLab専用リチウムポリマーバッテリー
充電時間	約4時間
充電温度	0℃ - 40℃


状態表示LED

充電LED：端末・タッチスクリーン上方の充電指示ランプ（右側）が充電状態を表示します。

状態表示LEDの説明


緑LED点灯	充電完了
赤LED点灯	充電中
赤LEDの点滅	充電エラー（バッテリー未装着等）
LED点灯なし	充電不能（電源ケーブルが正しく接続されていません）

状態表示LED：電源接続後、緑LED点灯




充電

手順1：
電源ケーブルを電源アダプターに挿入します。



手順2：アダプターを本体後方電源ジャックに挿入します。

電源ジャック：
電源アダプターに接続します。



手順3：RK25モバイルコンピュータをRK25 5スロットクレイドルのスロットに装着します。

警告：事前にRK25ガン式グリップ、ハンドストラップ又はRK25保護カバーを取り外す必要はなく、直接RK25本体を本体スロットに装着できます。Micro USBケーブル使用される場合、必ず先にMicro USBケーブルを抜いてからRK25本体を5スロットクレイドルに装着してください。

RK25 5-Slot Charging Cradle

Quick Start Guide

EN


>>
EN

RK25 5-Slot Charging Cradle allows simultaneous charging up to five RK25 mobile computers.

Overview

Open Your Box:

- ☒ 5-Slot Charging Cradle
- ☒ Adapter plus Power Cord
- ☒ Quick Start Guide



Important Charging Information

Power Supply	Input: AC 100-240V, 47-63Hz; output: DC 12V± 5%, 8-10A CipherLab approved
Battery Pack	3.8V, 4000mAh rechargeable Li-Polymerbattery CipherLab proprietary
Charging Time	Approx. 4 hours
Charging Temperature	0°C - 40°C


LED Indicator

Charging LED: The charging LED (right) located above the touch screen of the RK25 mobile computer shows the charging status

Charging LED Status	
Green, solid	Charging complete
Red, solid	Charging the mobile computer
Red, blink	Charging error (for instance, battery not in place)
No light	Not charging. It might result from the power cable which is not correctly connected.

Power Indicator LED:


The Power Indicator LED lights up in green when the unit is powered.



Charging


Step 1:

Connect the power cord with the adapter, and plug the power cord to an electrical outlet.



Step 2: Plug adapter plug to the back of the 5-Slot Charging Cradle.

Power jack:
Connect to the power supply



Step 3:

Insert the RK25 mobile computer(s) into the charging slots of the 5-Slot Charging Cradle.

Warning:

You can insert the device(s) into the charging slot(s) without detaching the rubber boot, handstrap, or pistol in advance. However, the micro USB cable must be removed before inserting RK25 mobile onto the 5-slot charging cradle.