



installation

For wall mount position, follow the steps listed below:

1. Drill two holes (6mm wide, 25.4mm deep) on the wall. 85mm apart each other. Please refer to the illustration on next page.
2. Push the screw anchor to its full depth into the hole.
3. Insert the screw through the base, and screw it into the anchor.



installation

For desktop position, place the stand on a flat space, and put the scanner on the holder directly.

Note: For wall installation, please take the base iron slab off to avoid unnecessary damages.




Illustration of Screw Hole Dimension & Package Content


instruction

1. Place the illustration on a proper position and fix it.
2. Drill the holes according to the marks.

Package Content:

- ✓ Holder*1
- ✓ Flexible Arm*1
- ✓ Base*1
- ✓ Stand Screws*2
- ✓ Plastic Anchors & Screws*2
- ✓ Rubber Pad*1





安裝/安裝


針對桌面放置位置，請將可調式自動掃描座置於平面的桌面上，再將掃描器直接放置於支架上。

针对桌面放置位置，请将底座放置在一个平面，并把扫描器直接放在支撑体上。

安裝/安裝

請照下面的步驟進行牆壁上的安裝：
针对墙面安装位置，请按照下列步骤：

1. 在牆壁上鑽出兩個約寬6mm深25.4mm的洞孔，且2個洞孔的距離約85mm。請參考下頁的孔位草稿圖。
在牆壁上钻两个孔（6毫米宽，25.4毫米深），两孔间距85毫米，请参考下页的插图。
2. 將塑膠製的螺絲錨插入鑽孔內。
用螺丝充分置于螺丝孔中。
3. 將掃描座的底座螺絲洞對準鑽孔後，插入螺絲並鎖緊。
将螺丝穿过底座，并拧紧。




注意:當於牆壁安裝時，請將底座內的鐵片取下以免造成不必要的損壞。
注: 如需进行墙面安装，请采取铁板来进行安装，以避免不必要的损失。

底座孔位尺寸圖與包裝明細 / 螺絲孔尺寸及套裝內容的插图



指示/提示

1. 將孔位草稿圖直接放在要安裝的壁上並固定好。
请将图纸安放在一个适当位置，并固定他。
2. 根據孔位草稿圖去進行鑽孔。
根据标志进行钻洞。



包裝明細 / 套件內容:

- ✓ 支架*1 / 支撐體*1
- ✓ 撐架*1 / 撐架*1
- ✓ 底座*1 / 底座*1
- ✓ 掃描座螺絲*2
扫描座螺丝*2
- ✓ 底座塑膠螺絲錨與螺絲*2
塑料螺丝刀，螺丝*2
- ✓ 橡膠墊片*1
橡胶垫片*1